





Contents

Timber Grade Guidelines	4
Icons for Recognition	6
Timber Flooring Facts and Variati	ions8
Mellow Beige	10-11
Antique White	12-13
Tan Brown	14-15
Terrace Grey	16-17
Acorn Brown	18-19
Midnight Grey	20
Natural Limed	21
Raw Neutral	22
Beige Ash	23
Smoked Brown	24
Coral Sand	25
Moss Grey	26
Casper White	27
Light Neutral	28
Tinge Clay	29
Specifications	30
Stair Nosing	32
Terms and Conditions	3/1

Timber Grade Guideline

Wonderwood Floors was founded with the goal of providing the best timber flooring to our customers. We source the finest timber from around the world for our products. We understand that installing your flooring is a significant project and knowing exactly what you are purchasing is critical.

Because each country and industry has its own set of standards and terminology, our timber experts have developed a guideline to our customers understand the quality of our timber floors.

Our timber experts have introduced two grades of timber: Prime and Natural



Prime Grade

Our prime grade floors are ideal for customers who want a cleaner, more uniform look with fewer natural characteristics inherent in the species. You can expect fewer flaws in our prime grade timber, such as knots, cracks, splits, sapwood, gum veins, and color variation. This means you will see fewer imperfections in our prime grade floors.



Natural Grade

For the customers who want to add more natural features to their home and flooring, natural grade timber will be what you are after.

With our natural grade floors, there will be visible knots with various sizes and quantities. Sapwoods and checks might be noticeable, while industrial filler may be used to companion the inherent of the natural features for broken knots and large size of check and crack.

With expecting of more natural elements of timber, that might contain knots, gum vein and insert trail. Variation between batches, or even between boards, that also means you are getting an absolute unique pattern from nature.

Note: Since both grades of our timber flooring, prime and natural, are visually graded by our timber floor experts and every timber floor is made by natural timber and based on their uniqueness, there is chance that some boards will be out of range or contain more natural beauty elements.



Launching Icons for Effortless Recognition



15mn Natural



15mm



15mm



15mm Prime

To streamline the selection process and help our customers effortlessly locate the most suitable products. Wonderwood has launched a straightforward and intuitive icons system.

These icons help identify the pattern, thickness, and grade of the products. Some colors may showcase multiple icons, giving customers a broader selection of options tailored to their aesthetic preferences. Consult with our professional retailers to explore how you can customize your home design.






Timber Flooring Facts and Variation

Wonderwood Timber Flooring is made from natural materials and differs in colour, texture and naturally occurring features both within and between individual pieces and batches of the same species. Samples, reproductions in printing, and photography are only for guidance; they provide a colour indication but are not necessarily representative of the overall effect or design.

Please be cautious when making your selection based on a single sample, reproductions in printing and photography, as these are only indications. Timber flooring products will vary from board to board, job to job, and from the samples on display in all jobs supplied. The colour of your flooring may change over time due to exposure to UV light and oxygen. Minor splits and wood checks/cracks are naturally occurring in timber. Timber flooring products continue to absorb and release moisture, expand and contract over their lifetime depending on local conditions, environmental conditions, and weather changes.

Even with proper installation, slight expansion and contraction, as well as board separation, is normal; however, excessive movement due to extreme weather conditions can be expected. It is critical to be aware of and to check conditions to ensure that your floor performs within tolerances. Installing your timber floor according to Wonderwood Floors installation guideline is crucial for a high-performing floor.

























Prime


Prime










































Plank Herringbone
















Plank

Herringbone





Specifications

		15mm Natural	15mm Prime	15mm Prime	15mm Prime		
		Plank	Plank	Herringbone	Chevron		
Board Size	Length	1900	1900	600	600		
	Width	190	190	120	90		
	Total Thickness	15	15	15	15		
	Wear Layer	3	3	3	3		
Pack Size	New	1.805 m² 5 Planks 18.2 kg	1.805 m² 5 Planks 18.2 kg	1.152 m² 16 Planks 11 kg	0.7344 m² 16 Planks 7kg		
	Old	2.888 m² 8 Planks	N/A	N/A	N/A		
Nesting		< 25% random short boards 0% random sho		hort boards			
Installation	Floating	Yes	Yes	No	No		
	Direct Stick	Yes	Yes	Yes	Yes		
Timber Species		European Oak					
Base		Multi-layer Cross Plywood					
Joining Profile		Tongue and Groove					
Surface Finish		Brushed Lacquer Matt Finish					
Edging		4 Sided Micro-Bevel					
Grade		Natural	Prime				
Moisture Content		8-12%					
Gloss Level		5-8% Super Matt					
Slip Resistance		P3					
Warranty	Residential Wear	20 Years					
	Commercial Wear	By Request					
	Structural	Lifetime					



Stair Nosing

Dimensions

	Finish	Length	Tread	Riser	Overhang
Overhang Nosing	Match colour	1900mm	125mm	30mm	25mm
Flushed Nosing		1900mm	125mm	40mm	N/A

Stair Nosing Profiles







Flushed Nosing with Insert



Overhang Nosing





Care and Maintenance

Wonderwood Timber Flooring is a quality product. By taking some precautions and following regular cleaning and maintenance routines, your floor will remain wonderful over time. Please find full instructions on the Wonderwood website, which includes the following:

- Routine Maintenance
- Preventative Maintenance
- Preventing Scratches & Dents
- Preventing Discoloration
- Preventing Expansion & Shrinkage
- Fixing Dings & Scratches
- Common Characteristics of Timber Floors

Installation Guidelines

Wonderwood Timber Flooring is designed to be installed by secret nailed, direct stick (trowel glue down), or as a floated floor. Please inspect each board in optimal lighting for visual defects, and ensure the locking system is functioning properly before and during installation. Products are considered to be of acceptable quality and structure once installed; do not install them if in doubt. Please note that only direct adhesive fixing system is suitable for Herringbone or Chevron parquetry installation. Heavy and bulky objects, such as island bench, should not be placed on floating floors, Wonderwood Timber Flooring must be cut in and installed around such objects. 8% to 10% of wastage floors is recommended to cover any sorting, trimming or visual selection during installation. 20% of wastage floors is expected for Herringbone or Chevron parquetry.

Timber Flooring Moisture Content

Before installation, a moisture meter must be equipped to ensure the moisture content of Wonderwood Timber Flooring remains in about 8%-12% on average, as timber floor is a natural product, a significant change of moisture content may result in product distortion. Please find full guidelines on the Wonderwood website, which includes the following:

- Preparation
- Installation
- Floating Method
- Direct Adhesive Method
- Finishing Molding

Warranty Terms and Conditions

All Wonderwood Timber Flooring comes with a Warranty from the date of purchase in accordance. Please find full descriptions of the following on the Wonderwood website:

- Residential Wear Warranty
- Lifetime Structure Warranty
- General Conditions
- Timber Flooring Facts & Variations
- Australian Consumer Law
- Making a Claim





